


VANISHER UPRIGHT MOTOR



REF. NO.	PART NUMBER	DESCRIPTION
1	46-2108-2	MOTOR COVER ASSEMBLY
1A	13-1091-1	MOTOR COVER
1B	02-0096-4	NUT
2	01-0071-9	SCREW
3	46-2024-1	BRUSH HOLDER
4	13-1121-6	BRUSH HOLDER SUPPORT
5	01-0375-4	SCREW
7	04-0397-2	END PLAY WASHER
8	28-0580-2	ARMATURE ASSEMBLY
9	28-0628-9	FIELD ASSEMBLY
10	24-0228-7	SPRING
11	46-2109-0	MOTOR BASE WITH GASKET
11A	13-1758-5	MOTOR BASE
11B	12-0495-7	GASKET
12	11-0159-1	SWITCH
14	13-2442-5	FAN
15	02-0208-5	BELT PULLEY NUT
16	30-0207-8	GROUP WASHER
17	01-0375-4	SCREW
18	04-0271-9	WASHER
19	04-0123-2	WASHER
20	26-0221-7	SPACER