


VANISHER
UPRIGHT
EXTERNAL
PARTS LIST

Pos.	PART No	DESCRIPTION	VLK-1	VLK-2	VLK-3
1	13-0947-5	Handle grip	1	1	1
2	28-1256-8	Cord assy 3"	1	1	1
2 B	09-1310-3	Cord extension	1	1	1
3	13-1462-4	Cord retainer	1	1	1
4	01-0283-0	Screw # 8 X ½	1	1	1
5	01-0290-5	Screw #10 X3/8	4	4	4
6	05-2142-7	Cord hook		2	2
	05-4089-8	Cord hook	2		
7	05-4051-8	Upper handle		1	1
	05-4091-4	Upper handle	1		
8	02-0141-8	Handle nut	2	2	2
9	01-2034-5	Screw handle	2	2	2
10	05-4049-2	Lower handle		1	1
	05-4090-6	Lower handle	1		
11	01-0270-7	Screw #6 X 3/8	1	1	1
12	13-1100-0	Knob height	1	1	1
15	37-0136-4	Felt	1	1	1
18	05-3343-0	Hood w/lens		1	
	05-4392-6	Hood w/lens	1		
	05-43-91-8	Hood w/lens			1
19	24-0271-7	Hood spring	2	2	2
20	02-0037-8	Nut # 10-32	2	2	2
21	04-0271-9	Star washer	2	2	2
22	13-2127-2	Bag support	1	1	1
23	01-0742-5	Screw 10-30 X 5/8	1	1	1
24	26-0001-3	Ball	1	1	1
25	24-0014-1	Knob spring	1	1	1
26	05-0997-6	Bag knob spacer	1	1	1
27	13-2126-4	Bag knob	1	1	1
28	01-0743-3	Screw 10-32 X ¾	1	1	1
29	01-0154-3	Screw # 6 X 5/16	1	1	1
30	02-0007-1	Hex. Nut 8-32	2	2	2
31	04-0271-9	Star washer	2	2	2
32	01-1247-4	Screw 8-32 X 3/8	1	1	1
33	46-2435-9	Permanent cloth bag			1
33-B	13-1601-7	Plastic strap	1	2	2
34	46-2436-7	Zipper bag assembly		1	
34-B	13-1128-1	Paper bag connector		1	
34-C	24-0233-7	Spring		1	
34-D	12-0548-3	Zipper bag hose		1	
35	46-2105-8	Bag coupling gasket	1	1	1
35-A	12-0550-9	Bag coupling gasket	1	1	1
35-B	13-2195-7	Bag coupling	1	1	1
36	45-0220-9	Paper bag		1	
37	45-0312-4	Clip bag	1		1
38	48410	Spring	1		1
39	46-2942-4	Dust cup assay	1		



VANISHER
UPRIGHT
INTERNAL
PARTS LIST

Pos.	PART No	DESCRIPTION	VLK-1	VLK-2	VLK-3
1	12-0258-9	Air duct gasket	2	2	2
2	13-1095-2	Right air duct	1	1	
	13-1843-5	Right air duct			1
3	46-2020-9	Motor assembly		1	1
	46-2542-2	Motor assembly	1		
4	01-1391-0	Screw 8-32 X 1/2	6	6	6
5	04-0065-5	Flat washer	6	6	6
8	25-1242-4	Rear wheel axle	2	2	2
9	01-0846-4	Screw 6-32 X 3/8	3	3	3
10	04-0026-7	Flat washer	5	5	5
11	05-3069-1	Plate cam guide	1	1	1
12	46-1898-9	Can spring assembly	1	1	1
13	05-3068-3	Front axle retainer	2	2	2
14	13-1089-5	Front wheel	2	2	2
15	03-0127-5	Type "B" rivet	1	1	1
16	04-0019-2	Flat washer	1	1	1
17	25-1065-9	Bushing	1	1	1
18	24-0229-5	Front axle spring	1	1	1
19	46-2971-3	Front axle assy	1	1	1
20	24-0234-5	Front axle spring	1	1	1
21	45-0312-4	Right Bearing support assy	1	1	1
21 A	12-0522-8	Bearing gasket	2	2	2
21 B	13-1252-9	Right bearing support	1	1	1
21 C	37-0130-7	Felt	2	2	2
21 D	13-1801-3	Left bearing support	1	1	1
21 E	46-2376-5	Left Bearing support assy	1	1	1
22	46-2375-7	Brush roll assy 12"	1	1	
22	46-2413-6	Brush roll assy 16"			1
23	25-0997-4	Retaining shaft	1	1	1
24	46-2035-7	Bottom plate with	1	1	
	46-2428-4	Bottom plate with			1
25	12-0814-9	Belt	1	1	1
26	12-0588-9	Motor noise reductor	1	1	1
27	02-0007-1	Nut 8-32	2	2	2
28	04-0276-8	Star Washer	2	2	2
29	28-0476-3	Ground lead	1	1	1
30	12-0515-2	Grommet heyco	1	1	1
31	46-2106-6	Switch actuator assy	1	1	1
31 A	13-1292-5	Switch actuator	1	1	1
31 B	25-1002-2	Switch shaft	1	1	
31 C	25-1224-2	Switch shaft			1
32	24-0259-2	Spring	1	1	1
33	13-1096-0	Left air duct	1	1	
	13-1842-7	Left air duct			1
34	13-1090-3	Rear Wheel	2	2	2
35	04-0587-8	Flat washer 5/16	4	4	4
36	04-0469-9	Clip ring	5	5	5
37	25-1233-3	Socket shaft	1	1	1
38	01-0931-4	Screw 6-32	1	1	1
39	04-0275-0	Star Washer	1	1	1
40	06-0567-5	Tube socket	1	1	1
41	05-3061-8	Handle cam	1	1	1
42	24-0249-3	Cam spring	1	1	1
43	25-1003-0	Cam shaft	1	1	1
44	04-0242-0	C. washer	2	2	2
45	23-0551-4	Pedal	1	1	1
46	24-0193-3	Spring	1	1	1
47	06-0838-0	Chassis	1	1	
	06-0840-6	Chassis			1
48	01-1609-5	Screw 10-32 X 1/2	2	2	4
49	12-0589-7	Bumper	1	1	
	12-0705-9	Bumper			1
50	04-0271-9	Star washer	2	2	4
51	02-0037-8	Nut 10-32	2	2	4
52	46-2036-5	Fan cover	1	1	1
52 A	12-0495-7	Fant cover gasket	1	1	1
53	01-1249-0	Screw 8-32	1	1	1
54	05-3872-8	Retaining plate			2